

1.3. ELASTIC PROPERTIES




Fig. 1.3.4.1. Resonance technique: standing waves excited in a parallelepiped.

electronic pulse generator excites the mechanical vibrations of a piezo-electric transducer glued to one of two plane-parallel faces of a specimen. An ultrasonic pulse whose duration is of the order of a microsecond is generated and transmitted through the specimen. After reflection at the opposite face, it returns and, when it arrives back at the transducer, it gives rise to an electronic signal, or echo. The whole sequence of such echos is displayed on the screen of an oscilloscope and it is possible to measure from them the time interval for transit. Usually, *X*-cut quartz crystals or ferroelectric ceramics are used to excite longitudinal waves and *Y*-cut quartz is used to excite transverse waves. In many cases, a circulator, or gate, is used to protect the receiver from saturation following the main ‘bang’. This method is rough because the beginning and the end of a pulse are not well characterized. Several improvements have therefore been made, mainly based on interferometric techniques (pulse-superposition method, ‘sing around’ method *etc.*). Nevertheless, if the absolute value of the ultrasonic velocity is not determined with a high accuracy by using pulse-echo techniques, this approach has proved valuable when relative values of ultrasonic velocities are needed, *e.g.* temperature and pressure dependences of ultrasonic velocities.

(i) *Pulse-superposition method.* A piezoelectric transducer initiates ultrasonic pulses in the specimen. These pulses echo back and forth within the specimen. A continuous-wave oscillator

is used to control the pulse repetition rate. When the repetition rate is adjusted so that the initiation of a pulse coincides with the return of the first echo from the preceding pulses, the change in the signal amplitude indicates superposition. The pulse rate is a measure of the travel time within the specimen.

(ii) ‘*Sing around method*’. The ‘sing around’ method for measuring the velocity of ultrasonic waves involves the use of two piezoelectric transducers, one at each end of the specimen. One transducer receives an impulse from the electronic generator and converts it into an ultrasonic pulse in the specimen. This pulse, after passing through the specimen, is detected by the receiving transducer. The received pulse triggers the electronic generator to initiate a succeeding pulse. The pulse repetition rate is a very sensitive probe for measuring changes of the ultrasonic velocity in the specimen. Relative variations of  $10^{-7}$  can be measured, such as temperature or stress dependences of the velocity.

1.3.5. Pressure dependence and temperature dependence of the elastic constants

1.3.5.1. Introduction

In a solid, the elastic constants are temperature and pressure dependent. As examples, the *temperature dependence* of the elastic stiffnesses of an aluminium single crystal within its stability domain (the melting point is 933 K) and the *pressure dependence* of the elastic stiffnesses of the ternary compound  $KZnF_3$  within its stability domain (the crystal becomes unstable for a hydrostatic pressure of about 20 GPa) are shown in Figs. 1.3.5.1 and 1.3.5.2, respectively.

We can observe the following trends, which are general for stable crystals:

(i) From 0 K to about  $\Theta_D/5$ , where  $\Theta_D$  is the Debye temperature, the elastic stiffnesses decrease according to a  $\Theta^4$  law. From  $\Theta_D/5$  to the beginning of the instability domain, the dependence is linear with  $\Theta$ . In addition,  $(\partial c_{ij}/\partial \Theta)_p = 0$  at 0 K as predicted by the third principle of thermodynamics.

(ii) For stable crystals, the *pressure dependence* of the elastic stiffnesses is linear as long as the applied pressure is small compared to the elastic stiffnesses. As an example, a typical order of magnitude for  $c_{11}$  in crystals is about 100 GPa and, within the experimental uncertainty, the pressure dependence of  $c_{11}$  does not depart from a linear behaviour up to at least 0.2 GPa.

These observations can be quantitatively justified on the basis of an equation of state of a solid:

$$f(T_{ij}, S_{ij}, X, \Theta) = 0,$$




Fig. 1.3.4.2. Block diagram of the pulse-echo technique.